



NOTES:

1. ALL JOINTS FROM MAIN TO HYDRANT SHALL BE RESTRAINED.
2. VALVE BOX AND COLLAR INSTALLED PER DETAIL W4.
3. REMOVE CHAINS AFTER INSTALLATION OF NEW HYDRANT.
4. CONNECT TRACER WIRE TO WIRE ON MAIN W/ SPLICE CONNECTOR.

FIRE HYDRANT FOR STANDARD BURY MAINS

STANDARD  
CONSTRUCTION  
DETAILS



CITY OF  
*savannah*  
WATER RESOURCES AND PUBLIC WORKS BUREAU  
Planning & Engineering

SCALE: N.T.S.  
DATED: JAN 2017  
PLATE NUMBER:  
**W36**